
601 602 Voltage adjustment Sense module module 603

Sa Jan 9



RECEIVED

JAN 1 0 2003 **OFFICE OF PETITIONS**



Adjust DC-DC converte-provided rollage such that the voltage is at a maximum current voltage level when the current drawn is at a maximum load current level and the voltage is at a minimum current voltage level when the current drawn is at a minimum current voltage level when the current drawn is at a minimum current voltage level when the current drawn is at a minimum load current level.

RECEIVED

JAN 1 0 2003

OFFICE OF PETITIONS



Sense current drawn from DC - DC converter

Convert sensed current to a voltage signal indicating the sensed current

Adjust the voltage signal that indicates the sensed current such that the voltage signal is at a maximum level when the current drawn is at a minimum but nonzero load current level and so that the voltage signal is at a minimum level when the current drawn is at a maximum load current level.

Add the adjusted voltage signal to the voltage provided by the DGDC Convertor

~ 803

804